

# USER GUIDE


## CYCLE TIMER



The **CYCLE TIMER** controls any 120V equipment such as irrigation pumps, fogger, fans or CO<sub>2</sub> generators on periodic cycles. The output is repeatedly turned **ON** and **OFF** for periods corresponding to the **ON** and **OFF** times.



Plug equipment into output cord (piggy back cord).



The **OUTPUT** indicator is lit only when power is supplied to the **output**.

**Specifications :**  
Load: 120V 12A  
5-ft Piggy Back Cord.

## Setting your times

Simply rotate the knobs to set:

**ON Time** from 1 to 60 minutes.

**OFF Time** from 5 minutes to 12 hours.

## Selecting the operating mode

Simply slide the switch to select:

**Day** : the output is activated during the day only.

**24 h** : the output is activated day and night.

**Night** : the output is activated during the night only.

The **LIGHT SENSOR** serves as the day/night detector.



The **OUTPUT** indicator is lit when power is applied to output cord (piggy back cord).

**For Warranty & Customer Service  
Please visit [www.gardencontrols.com](http://www.gardencontrols.com)  
or contact us at  
(855) 262-1800 or at [info@gardencontrols.com](mailto:info@gardencontrols.com)**

# GUIDE D'UTILISATION **GARDEN CONTROLS**


## MINUTERIE PÉRIODIQUE

Le **CYCLE TIMER** contrôle tous les équipements 120V tels que les pompes d'irrigation, les humidificateurs, les ventilateurs ou les générateurs de CO2 en cycles périodiques.

La sortie est activée et désactivée de manière répétée pour les périodes correspondant aux temps d'activation (**ON**) et de désactivation (**OFF**).



Branchez l'équipement dans la **prise de sortie** du cordon d'alimentation.



L'indicateur **OUTPUT** est allumé lorsque le cordon de sortie (ou cordon d'alimentation) est mis sous tension.

### **Caractéristiques :**

Charge : 120V 12A

5 pieds de cordon d'alimentation.

## Réglage de la minuterie

Tournez les boutons pour définir:

**Temps "ON"** de 1 à 60 minutes.

**Temps "OFF"** de 5 minutes à 12 heures.

## Sélection du mode de fonctionnement

Poussez l'interrupteur pour sélectionner:

**"Day"** : la sortie est activée uniquement pendant la journée.

**24 h** : la sortie est activée jour et nuit.

**"Night"** : la sortie est activée uniquement pendant la nuit.

Le **capteur de lumière** sert de détecteur jour / nuit.

L'indicateur **OUTPUT** est allumé lorsque le cordon de sortie (ou cordon d'alimentation) est mis sous tension.



Pour le service à la clientèle et la garantie  
visitez [www.gardencontrols.com](http://www.gardencontrols.com)  
ou contactez-nous au  
(855) 262-1800 ou à [info@gardencontrols.com](mailto:info@gardencontrols.com)